



Beach flags

Installation manual
English

Contents

- 1 General information
 - 1.1 Introduction
 - 1.2 Contact
 - 1.3 Technical data
- 2 Safety instructions
 - 2.1 General
 - 2.2 Not allowed
- 3 Installation
 - 3.1 General
 - 3.2 Installation step by step

1 General information

1.1 Introduction

Congratulations with your new advertising beach flag. We hope you will get more attention with this high quality beach flag.

This manual describes the installation and safety instructions for the following beach flags

- Beach flag Straight
- Beach flag Concave
- Beach flag Flying
- Beach flag Convex
- Beach flag Angled
- Beach flag Shark
- Beach flag Dolphin
- Beach flag Block

This user manual contains important information for safe installation and use of our beachflags. Use the manual with the installation to avoid dangerous situations.

1.2 Contact

ProFlags BV / Beachflags.com
Eenspan 19 B/C
3897 AL, Zeewolde
The Netherlands


+31 (0) 85 401 4648
info@beachflags.com
www.beachflags.com

1.3 Technical information

Below you will find an overview with the dimensions of the beach flags

Beach flag Straight

	Printing (wxh), cm	Total height, cm
Size XS	60x186	250
Size S	60x240	300
Size M-Wide	90x300	400
Size M	70x330	420
Size L	75x380	500



Beach flag Shark

	Printing (wxh), cm	Total height, cm
Size XS	68x200	250
Size S	68x250	300
Size M	68x350	400
Size L	68x450	500



Beach flag Dolphin

	Printing (wxh), cm	Total height, cm
Size XS	80x180	250
Size S	112x200	250
Size M	112x300	350
Size L	112x400	450



Beach flag Angled

	Printing (wxh), cm	Total height, cm
Size XS	60x186	250
Size S	60x240	300
Size M-Wide	90x300	400
Size M	70x330	420
Size L	75x380	500



Beach flag Convex

	Printing (wxh), cm	Total height, cm
Size XS	60x180	250
Size S	60x240	300
Size M-Wide	90x300	400
Size M	70x330	420
Size L	75x380	500



Beach flag Concave

	Printing (wxh), cm	Total height, cm
Size XS	60x186	250
Size S	60x240	300
Size M-Wide	90x300	400
Size M	70x330	420
Size L	75x380	500



Beach flag Flying

	Printing (wxh), cm	Total height, cm
Size XS	70x150	200
Size S	90x180	250
Size M	100x240	340
Size L	100x300	400



Beach flag Block

	Printing (wxh), cm	Total height, cm
Size XS	60x160	200
Size S	72x240	300
Size M	72x340	400
Size L	72x440	500



2 Safety instructions

2.1 General

Safety is a combination between measure implemented during the design and measures taken by the user of the beach flag. The beach flag is designed to function as a advertising product. It is designed to be safe during installation if the installation is carried out as described in this manual. The purpose of these safeguards is to prevent accidents during the expected lifetime of the beach flag.

Parts and accessories, which are not approved by the manufacturer, may result in personal injury and / or damage to the product or its functioning. Therefore, use only original parts which are specifically made for the product, and mount these parts with proper tools.

Warnings and symbols

Warning labels, such as shown below, warn the user for risks, these are risks which are by the design not or not enough be prevented, and for situations in which technical safety device not or not entirely effective.

In this manual the following symbols are used:



- Inattention may have adverse effects to people



- Not following the instructions in this manual may damage the beach flags

Compliance with requirements



- Use the beach flags only when the weather permits.
- Install the beach flag base in a proper way to avoid dangerous situations (see manual of the various beachflag bases)
- The manufacturer is not responsible for the any damage by course of these kind of actions.
- The user must know this manual before install or using the beach flags
- If activities are not described in this manual in all circumstances the user must contact the supplier

Cleaning the beach flags



- All our beach flags are washable
- Disassemble the beach flag before washing
- Only wash the flag self
- Wash the flags on 30 degrees
- Clean the pole and base with a piece of non scratching fabric and water

2.2 Not allowed



- Never use the beach flags when the windforce is more then 5 bft (Beaufort scale)

3 Installation

3.1 General

Before installation make sure that the beach flag is complete. The following parts are needed for a proper installation:

1. Beach flag pole (4 parts (XS - M) or 5 parts (L))
2. Flag with pocket, 2 eyelets located at the bottom of the pocket
3. Elastic with ball
4. Tension mechanism, mounted on the bottom part of the pole (thickest part)
5. Base (optional, could be ordered separate)



3.2 Installation

Step 1 Open the package carefully and slide the beach flag out of the box




Step 2

Open the transport bag and remove the pole, flag and base (if ordered, depending on the base)



Step 3

Connect the parts of the pole by sliding them in each other. This can only be done in one way
Notice: the pole can be made out of 4 or 5 parts depending on the size of the beach flag.



Step 4

Slide the flag over the smallest part of the pole until the pole is at the end of the pocket.
Double check if the pole reach the end of the pocket.



Step 5


Install the elastic as shown on the pictures below. Put the elastic through the top eyelet. The plastic ball will stick to the top eyelet. Put the elastic through the lower eyelet as shown below.



Step 6 Place the elastic behind the hook of the tension mechanism.



Step 7 Slide the tension mechanism to the bottom of the pole until the beach flag is completely tensioned (not to tight!). Fasten the mechanism by turning the screw clockwise by hand.



Step 8 Your beach flag is ready! Place the beach flag on a base or in a holder. If you use the beach flag outside please make sure the beachflag can rotate 360 degrees to avoid damage.

Have fun with your beach flag!

