


# EXPLODED VIEW EDHARD DOSEERMACHINE POWER BASE UNITS


## POWER BASE HOUSING ASSEMBLY Parts List



Ref. No.	Description	Qty.	Part Number for Model:		
			MK	MKH	MKS
1	Screw	1	P-2118	P-2118	P-2118
2	Pump Driver Assembly	1	P-3029	P-3029	PS-3146
3	Trip Pin	1	P-2046	P-2046	P-2046
4	Trip Arm Assembly	1	P-3030	P-3030	P-3030
5	Screw	10	P-2115	P-2115	P-2115
6	Power Base Housing Assy.	1	P-3028	P-3028	PS-3170
7	Boot	1	P-2072	P-2072	P-2072
8	Trigger Switch	1	P-2141	P-2141	P-2141
9	Timer Board 120V	1	P-3700	P-3710	PS-3708
10	Screw	5	P-2116	P-2116	P-2116
11	Keypad	1	P-2085	P-2085	P-2085
12	Power Cord Assy.	1	P-3554	P-3554	P-3554
13	Fuse	1	P-2601	P-2616	PS-2617
14	Fuse Holder Assy.	1	P-3178	P-3178	P-3178
15	On/Off Switch	1	P-2142	P-2142	P-2142
16	Plate On/Off	1	P-2717	P-2717	P-2717
17	Receptacle - Accessory	1	PVS-21198	PVS-21198	PVS-21198
18	Screw	2	P-20948	P-20948	P-20948
19	Driver Seal Assy.	1	PV-3595	PV-3595	PV-3595
20	Driver Seal Top Plate Sub-Assy.	1	PV-20932	PV-20932	PV-20932
21	Screw	4	PT-20090	PT-20090	PT-20090
22	Guard (not shown)	1	PV-20918	PV-20918	PV-20918
21	Screw	1	PS-2512	PS-2512	PS-2512
22	Pump Safety Clamp	1	PS-2511	PS-2511	PS-2511

## BASE ASSEMBLY: MODEL MK

### Parts List



Ref. No.	Description	Qty.	Part Number
1	Brake Assembly	1	P-3062
2	Screw	2	P-2187
3	Motor Assembly	1	P-3019
4	Motor Bolt	2	P-2121
5	Washer	2	P-2124
6	Nut	2	P-2122
7	Gear & Idler Assembly	1	P-3021
8	Output Gear Assembly	1	P-3022
9	Gearbox Cover	1	P-2035
10	Screw	3	P-2120
11	Capacitor Assembly	1	P-3033
12	Screw	2	P-2116
13	Base	1	P-2037
14	Rubber Foot Assembly	4	P-3423



**BakeryShop**®