

Fitting



Use **PLAYER'S HEIGHT** to determine club size

Determine **PLAYER'S DRIVER SWING SPEED** to choose **ULTRALIGHT** or **TOUR SERIES**.

The 2/3 Solution

To help kids develop a proper release with high handspeed, the driver should never be too long. It should fit as it does for adults. Adult drivers are 2/3 their height.

Player's Height x 2/3 (667) =

| U/L ULTRALIGHT | TOUR SERIES |
|--|--|
| <p>Ultralight clubs are designed with lighter clubheads and more flexible shafts for the beginning golfer with less clubhead speed.</p> <p>Beginner to Intermediate</p> | <p>TOUR SERIES clubs are designed for the intermediate to advanced golfer with more clubhead weight and longer, stiffer shafts.</p> <p>Intermediate to Advanced</p> |
| <p>APPROX. AGE: 12</p> <p>ULTRA LIGHT 63" TALL</p> <p>SWING SPEED: up to 73 mph</p> | <p>APPROX. AGE: 12</p> <p>TOUR SERIES 63" TALL</p> <p>SWING SPEED: 74 mph & up</p> |
| <p>APPROX. AGE: 11</p> <p>ULTRA LIGHT 60" TALL</p> <p>SWING SPEED: up to 68 mph</p> | <p>APPROX. AGE: 11</p> <p>TOUR SERIES 60" TALL</p> <p>SWING SPEED: 69 mph & up</p> |
| <p>APPROX. AGE: 10</p> <p>ULTRA LIGHT 57" TALL</p> <p>SWING SPEED: up to 63 mph</p> | <p>APPROX. AGE: 10</p> <p>TOUR SERIES 57" TALL</p> <p>SWING SPEED: 64 mph & up</p> |
| <p>APPROX. AGE: 9</p> <p>ULTRA LIGHT 54" TALL</p> <p>SWING SPEED: up to 58 mph</p> | <p>APPROX. AGE: 9</p> <p>TOUR SERIES 54" TALL</p> <p>SWING SPEED: 59 mph & up</p> |
| <p>APPROX. AGE: 8</p> <p>ULTRA LIGHT 51" TALL</p> <p>SWING SPEED: up to 53 mph</p> | <p>APPROX. AGE: 8</p> <p>TOUR SERIES 51" TALL</p> <p>SWING SPEED: 54 mph & up</p> |
| <p>APPROX. AGE: 7</p> <p>ULTRA LIGHT 48" TALL</p> | <p>Use player's HEIGHT to</p> |
| <p>PLAYER'S HEIGHT IN SHOES</p> <p>64"</p> <p>63" (160 cm)</p> <p>62"</p> <p>61"</p> <p>60" (152 cm)</p> <p>59"</p> <p>58"</p> <p>57" (145 cm)</p> <p>56"</p> <p>55"</p> <p>54" (137 cm)</p> <p>53"</p> <p>52"</p> <p>51" (130 cm)</p> <p>50"</p> <p>49"</p> <p>48" (122 cm)</p> | |

