

Step  
1

Press the start button until the green light flashes.



Step  
2

Peel plastic off of glue dot on back of label and place it at the location you would like to monitor.

Step  
3

The datalogger automatically stops after the configured time.

Download the software via [www.praxas.com/support/downloads](http://www.praxas.com/support/downloads) to get the results.



For a comprehensive overview of the temperature fluctuations that occurred during distribution, all temperature readings are displayed in a spreadsheet.

[Download now](#)