



PRODUCT INFORMATION

TEA CLEANER

Removes build up of tea stains

FEATURES AND BENEFITS

- Removes tea stains
- Removes tea tannin and stains from porcelain, ceramic and glass tea makers, tea pots and tea cups
- Revives glass tea brewers, will make glass crystal clear and sparkling again
- Certified for organic use, is free from phosphates and genetically modified organism



INSTRUCTIONS

For Glass tea brewers

- Ensure tea maker and basket are empty
- Fill tea maker with 1500ml water. Attach basket to jug post. Select 100 °C and press HOT WATER button to boil. Cool for 1 minute. Lower basket by pressing BASKET button for 2 seconds.
- Place contents of tea cleaner sachet in water
- Allow to stand for 5 minutes
- Empty tea maker and thoroughly rinse with potable water before use.

For tea cups, pots and other tea brewing equipment

- Add 1 sachet of Tea Cleaner to 1500 ml of hot water and stir to dissolve.
- Fill tea cup, tea pot or other tea brewing equipment with the tea cleaner solution
- Allow to stand for 10 minutes
- Discard solution and rinse with potable water before reuse.

AVAILABLE IN

Product	Type of unit pack	Tablet weight	# of sachets per unit	# of units per carton	# of sachets per carton	Product code/ individual	Product code/ carton
Tea Cleaner	Sachet	10g (0.35oz)	4	12	48	E27231	E27220

