



Power Switch

1. Power Socket
2. Learn/Switch Button & LED Indicator
3. Plug

Slimme Stekker

1. Stopcontact
2. Leer/Schakelknop & LED-indicator
3. Plug / Stekker

ENGLISH

Power Switch PSS-S3 is only compatible with SA and Q-series alarm systems

Getting Started

1. Plug the Power Switch into the power outlet. The LED will flash twice.
2. Refer to your Control Panel manual and enter learning mode for Control Panel.
3. Press and hold the Learn/Switch button for about 10 seconds and release the button when LED flashes once. The Power Switch will send learning signal to Control Panel.
4. If learning is successful, the Power Switch LED will flash twice. Refer to Control Panel manual to complete the learning process.

Operation

- Plug the home appliance you want to control into the Power Switch. The appliance must be turned ON.
- The Power Switch can be remotely controlled using Blaupunkt's **Connect2Home and Secure4Home** smartphone application. Please refer to your Control Panel manual for detail.
- You can toggle on/off the Power Switch manually by pressing the Learn/Switch

LED Indicator

ON: Power Switch is turned ON.
OFF: Power Switch is turned OFF

Maximum Load

110V: 1760W 16A
230V: 3680W 16A

Specification

Environmental Condition:

-10 °C to 40 °C, relative humidity 85% non-condensing.

Radio:

868 MHz

NEDERLANDS

Slimme Stekker PSS-S3 is alleen compatibel met SA en Q-serie Smart Home systemen

Beginnen

1. Steek de stekker in het stopcontact. De LED zal tweemaal knipperen.
2. Zet het Regelpaneel in de leer-modus. Raadpleeg indien nodig de handleiding van uw Regelpaneel om na te gaan hoe dit moet.
3. Druk en houd de Leer/Schakelknop ingedrukt voor ongeveer 10 seconden en laat de knop pas los wanneer het LED eenmaal knippert. De PSS-S3 zal het leersignaal naar het Regelpaneel sturen.
4. Als het leren succesvol is, zal het LED tweemaal knipperen. Raadpleeg de Regelpaneel handleiding om het leerproces te voltooien.

Werking

- Steek het toestel dat u wilt bedienen in de Slimme Stekker. Het toestel moet AAN staan.
- De Slimme Stekker kan van afstand worden bestuurd door middel van het Blaupunkt Home Connect portaal, de Secure4Home (Q-Serie) en de Connect2Home (SA serie) smartphone applicatie. Raadpleeg alstublieft uw Regelpaneel en Home Connect server handleidingen voor details.
- U kunt de Slimme Stekker ook handmatig aan / uit zetten door op de Leer/Schakel knop te drukken

LED-Indicator

ON: Slimme Stekker staat AAN.
OFF: Slimme Stekker staat UIT.

Maximale Belasting

110V: 1760W 16A
230V: 3680W 16A

Specificatie

Omgevingswaarden:

-10°C tot 40°C, relatieve luchtvochtigheid 85% niet-condenserend.

Radiofrequentie:

868 MHz