

Operating manual INCLINOMETER ProDigit MICRO



1. Product Features

1. Aluminum alloy enclosure (light weight and durable)
2. Relative/absolute measurement interchange at any position
3. With 3 built-in magnets in measuring surface, which is convenient to be attached to the object measuring workpiece
4. Power-off automatically in 5 minutes
5. Portable size, convenient to co-work with other measuring tools and enlarge measuring range

2. Technical Parameters

1. Measuring range: 4°90°
2. Resolution: 0.05°
3. Accuracy: ±0.2°
4. Repeatability: 0.1°

5. Battery: 9V battery
6. Working temperature: 0°C ~40°C
7. Dimension: 57*57*30.5mm
8. With 3 diameter 10mm built-in magnets in measuring surface, which is convenient to be attached to the object measuring workpiece
9. Absolute zero measurement based on the horizontal surface
10. N. Weight: 0.13kg

3. Operating Instructions:

1. Press the «ON/OFF» button, it turns on, and the LCD displays absolute horizontal angle. Press «ON/OFF» button again, it turns off.
2. Measurement Initially displays 0.0° on the LCD at the beginning, when it displays «A» on the left side on the right side, it means the left side is higher and right side lower; when it displays «▼» on the left side «▲» on the right side, it means the left side is lower and right side higher.
3. Put the instrument on the horizontal stand, and press the «ZERO» button, the value returns to zero, and the read-out is the angle value measured angle value relatively to the horizontal stand.
4. Press the «HOLD» button, the value on the screen will be locked.
5. The magnets at the bottom allows the instrument to be attached onto iron material measurement object. Press the «ZERO» button, reset the value to proceed relative measurement.

4. Application:

More widely application is in wood processing industry (especially in furniture manufacturing industry) for wood angle accurate cutting; auto repair industry for tiring assembling angle accurate controlling; in machining industry for machine tool working angle accurate positioning, and large vehicle arm rotation angle etc.

5. Packing:

Product size: 57*57*30.5mm Product packing: white box/93*82*40mm

WARRANTY DOESN'T EXTEND TO FOLLOWING CASES:

1. If the standard or serial product number will be changed, erased, removed or will be unreadable.
2. Periodic maintenance, repair or changing parts as a result of their normal runout.
3. All adaptations and modifications with the purpose of improvement and expansion of normal sphere of product application, mentioned in the service instruction, without tentative written agreement of the expert provider.
4. Service by anyone other than an authorized service center.
5. Damage to products or parts caused by misuse, including, without limitation, misapplication or negligence of the terms of service instruction.
6. Power supply units, chargers, accessories, wearing parts.
7. Products, damaged from mishandling, faulty adjustment, maintenance with low-quality and non-standard materials, presence of any liquids and foreign objects inside the product.
8. Acts of God and/or actions of third persons.
9. In case of unwarranted repair till the end of warranty period because of damages during the operation of the product, it's transportation and storing, warranty doesn't resume.

For more information you can visit our website WWW.ADAINSTRUMENTS.COM or write the letter with your questions on info@adainstruments.com

WARRANTY CARD

Name and model of the product _____

Serial number _____ date of sale _____

Name of commercial organization _____ stamp of commercial organization _____

Warranty period for the instrument exploitation is 24 months after the date of original retail purchase.

During this warranty period the owner of the product has the right for free repair of his instrument in case of manufacturing defects.

Warranty is valid only with original warranty card, fully and clear filled (stamp or mark of the seller is obligatory).

Technical examination of instruments for fault identification which is under the warranty, is made only in the authorized service center.

In no event shall manufacturer be liable before the client for direct or consequential damages, loss of profit or any other damage which occur in the result of the instrument outage.

The product is received in the state of operability, without any visible damages, in full completeness. It is tested in my presence. I have no complaints to the product quality. I am familiar with the conditions of warranty service and I agree.

purchaser signature _____

Before operating you should read service instruction!

If you have any questions about the warranty service and technical support contact seller of this product

Certificate of acceptance and sale

_____ No _____

name and model of the instrument

Corresponds to _____

designation of standard and technical requirements

Data of issue _____

Stamp of quality control department

Price

Sold _____

name of commercial establishment

Date of sale _____

Руководство по эксплуатации Цифровой угломер ProDigit MICRO



1. Функции:

- Корпус из алюминиевого сплава (легкий и прочный)
- Относительное/абсолютное измерение угла.
- 3 встроенных магнита на измерительной поверхности. Удобно прикреплять к металлическому объекту.
- Автоматическое отключение через 5 мин.
- Маленький размер, удобно носить с другими измерительными инструментами.

2. Технические характеристики

Диапазон измерения 4x90°
Разрешение 0.05°

Точность ±0.2°
Батарея 9В
Рабочая температура 0°C ~40°
Размеры 57x57x30.5 мм
Размер упаковки 93*82*40 мм
3 встроенных магнита диаметром 10 мм на измерительной поверхности
Вес 0.13 кг

3. Работа с уровнем

1. Чтобы включить прибор, нажмите кнопку «ON/OFF». На дисплее отобразится абсолютное нулевое измерение.
2. На дисплее отображается 0.0°. Если приподнять левую сторону, то в левой части дисплея появляется стрелка вверх, а в правой части дисплея стрелка вниз. Это означает, что левая сторона выше правой.
3. Измерение относительных углов. Установите инструмент на поверхность от которой необходимо измерить относительный угол и нажмите кнопку «ZERO». Значение станет 0 и затем установите угломер на следующую поверхность. На дисплее отобразится значение относительного угла.
4. Нажмите на кнопку HOLD, чтобы зафиксировать значение на дисплее.
5. Магниты на основании инструмента позволяют прикрепить прибор к металлическому измеряемому объекту. Нажмите на кнопку «ZERO» для сброса значения. Чтобы выключить прибор, снова нажмите на кнопку «ON/OFF».

4. Применение:

Контроль и измерение угла наклона любой поверхности. Применяется в деревообрабатывающей промышленности (особенно в изготовлении мебели) для точного углового распила. В авторемонтной промышленности, в автомобильной промышленности, столярные работы, установка направляющих для гипсокартонных конструкций и т.д.

ГАРАНТИЙНЫЕ ОБЯЗАТЕЛЬСТВА НЕ РАСПРОСТРАНЯЮТСЯ НА СЛЕДУЮЩИЕ СЛУЧАИ:

1. Если будет изменен, стерт, удален или будет неразборчив типовой или серийный номер на изделии;
2. Периодическое обслуживание и ремонт или замену запчастей в связи с их нормальным износом;
3. Любые адаптации и изменения с целью усовершенствования и расширения обычной сферы применения изделия, указанной в инструкции по эксплуатации, без предварительного письменного соглашения специалиста поставщика;
4. Ремонт, произведенный не уполномоченным на то сервисным центром;
5. Ущерб в результате неправильной эксплуатации, включая, но не ограничиваясь этим, следующее: использование изделия не по назначению или не в соответствии с инструкцией по эксплуатации на прибор;
6. На элементы питания, зарядные устройства, комплектующие, быстроизнашивающиеся и запасные части;
7. Изделия, поврежденные в результате небрежного отношения, неправильной регулировки, ненадлежащего технического обслуживания с применением некачественных и нестандартных расходных материалов, попадания жидкостей и посторонних предметов внутрь.
8. Воздействие факторов непреодолимой силы и/или действие третьих лиц;
9. В случае негарантийного ремонта прибора до окончания гарантийного срока, произошедшего по причине полученных повреждений в ходе эксплуатации, транспортировки или хранения, и не возобновляется.

Для получения дополнительной информации Вы можете посетить наш сайт WWW.ADAINSTRUMENTS.COM или написать письмо на электронный адрес info@adainstruments.com

ГАРАНТИЙНЫЙ ТАЛОН

Наименование изделия и модель _____

Серийный номер _____ Дата продажи _____

Наименование торговой организации _____

Штамп торговой организации _____ мп.

Гарантийный срок эксплуатации приборов составляет 24 месяца со дня продажи и распространяется на оборудование, ввезенное на территорию РФ официальным импортером. В течении гарантийного срока владелец имеет право на бесплатный ремонт изделия по неисправностям, являющимся следствием производственных дефектов.

Гарантийные обязательства действительны только по предъявлению оригинального талона, заполненного полностью и четко (наличие печати и штампа с наименованием и формой собственности продавца обязательно).

Техническое освидетельствование приборов (дефектация) на предмет установления гарантийного случая производится только в авторизованной мастерской. Производитель не несет ответственности перед клиентом за прямые или косвенные убытки, упущенную выгоду или иной ущерб, возникшие в результате выхода из строя приобретенного оборудования.

Правовой основой настоящих гарантийных обязательств является действующее законодательство, в частности, Федеральный закон РФ "О защите прав потребителя" и Гражданский кодекс РФ ч. II ст. 454-491. Товар получен в исправном состоянии, без видимых повреждений, в полной комплектности, проверен в моем присутствии, претензий по качеству товара не имею. С условиями гарантийного обслуживания ознакомлен и согласен.

Подпись получателя _____

СВИДЕТЕЛЬСТВО О ПРИЕМКЕ И ПРОДАЖЕ

№ _____
НАИМЕНОВАНИЕ И ТИП ПРИБОРА

Соответствует _____
обозначение стандарта и технических условий

Дата выпуска _____

Штамп ОТК (клеимо приемщика)

Цена

Продан(а) _____

Дата продажи _____

Перед началом эксплуатации внимательно ознакомьтесь с инструкцией по эксплуатации!

По вопросам гарантийного обслуживания и технической поддержки обращаться к продавцу данного товара