

PLEASE USE THIS TEMPLATE TO DETERMINE COMPATIBILITY WITH YOUR COPIER/PRINTER

1 Cut out A and B.



2 Fold part A.

3 Glue or staple part A to part B.

4 Fit & Test template on your machine.

5 Order the actual PaperLock.

6 Mount the actual PaperLock.



DO NOT position the Bracket over Gaps, Ventilation Outlets, Screws, Holes, etc.

DO NOT position the Bracket over 2 different plastic machine-parts.

Print on papersize A3 and after printing check dimensions.

	SCHAAL: 1:1	ONTWERPER: _	OPMERKINGEN: -
	MAATEENHEID: mm	GETEKEND: _	
	AM. PROJECTIE	GEWIJZIGD: _	DATUM: _
	INDIEN NIET ANDERS AANGEGEVEN TOLERANTIE ±0,2mm		