# **1" PGV & PGV JAR TOP**

# **FEATURES**

- · External and internal manual bleed allows quick and easy "at the valve" activation
- Double-beaded diaphragm seal design assures leak-free performance
- Durable glass-filled nylon threaded bonnet ring allows easy access without tools (Jar Top)
- Optional: DC latching solenoids enable Hunter's ٠ battery-powered controllers
- · Captive bonnet bolts provide hassle-free valve maintenance
- · Low flow capability allows use of Hunter's micro irrigation products
- Encapsulated 24 VAC solenoid with captive plunger for hassle-free service
- Temperature rating: 150° F
- Warranty period: 2 years
- Flow control
- Accu Sync<sup>®</sup> pressure regulation
- Optional reclaimed water ID handle

## **OPERATING SPECIFICATIONS**

• Flow:

VALVES

- PGV-100: 0.2 to 40 GPM
- PGV-101: 0.2 to 40 GPM
- Recommended pressure range: 20 to 150 PSI

## SOLENOID SPECIFICATIONS

- 24 VAC solenoid
  - 350 mA inrush, 190 mA holding, 60 Hz
  - 370 mA inrush, 210 mA holding, 50 Hz

## FACTORY INSTALLED OPTIONS

- · Valve without solenoid
- · DC latching solenoid

## **USER INSTALLED OPTIONS**

- Solenoid conduit cover (P/N 464322)
- DC latching solenoid (P/N 458200)
- Accu Sync pressure regulator\*
- Reclaimed water ID handle for PGV-101 models (P/N 269205)
- Advanced Feature descriptions on page 109
- \* Accu Sync product information on page 117



Flow: 0.2 to 40 GPM

Size: 1"

**PGV-100G** Inlet Diameter: 1" Height: 5" Length: 41/2" Width: 21/2"



PGV-100JT-G Inlet Diameter: 1" Height: 51/2" Length: 41/2" Width: 31/4"

**PGV-101G** Inlet Diameter: 1" Height: 5"

Length: 41/2"



PGV-101JT-G Inlet Diameter: 1" Height: 51/2" Length: 41/2" Width: 31/4"

#### PGV Jar Top





PGV 1" - SPECIFICATION BUILDER: ORDER 1 + 2 + 3 + 4				
1 Model	2 Inlet/Outlet	3 Options (Factory Installed)	4 Options (User Installed)	
<b>PGV-100G</b> = 1" Globe valve, without flow control	(blank) = NPT threads	(blank) = No Option	(blank) = No option	
<b>PGV-101G</b> = 1" Globe valve, with flow control	<b>S</b> = Slip x Slip (only available in 100G and 101G models)	<b>DC</b> = DC latching solenoid <b>LS</b> = Valve without solenoid	<b>R</b> = Reclaimed water ID handle ( <i>Except for PGV-100</i> )	
<b>PGV-100A</b> = 1" Angle valve, without flow control			<b>CC</b> = Solenoid conduit cover	
<b>PGV-101A</b> = 1" Angle valve, with flow control			<b>DC</b> = DC latching solenoid	
<b>PGV-100</b> = 1" Globe valve, without flow control	<b>MM</b> = Male x male (NPT)		<b>AS-ADJ</b> = Accu Sync <sup>®</sup> adjustable pressure regulator	
<b>PGV-101</b> = 1" Globe valve, with flow control	<b>MB</b> = Male NPT x 1" Barb		<b>AS-xx*</b> = Accu Sync pressure regulator <b>20</b> * = 20 PSI, <b>30</b> * = 30 PSI, <b>40</b> * = 40 PSI	
	<b>MB125</b> = Male NPT x 1¼" Barb		<b>50</b> * = 50 PSI, <b>70</b> * = 70 PSI	

#### Example:

PGV-101G-S-DC = 1" Globe valve, with flow control, slip x slip, and DC latching solenoid

### **PGV JAR TOP - SPECIFICATION BUILDER:** ORDER 1 + 2 + 3 + 4

1 Model	2 Inlet/Outlet	3 Options (Factory Installed)	4 Options (User Installed)
<b>PGV-100JT</b> = 1" Globe jar top valve, without flow control	<b>G</b> = Female NPT	(blank) = No option	(blank) = No option
	<b>GS</b> = Slip x Slip	LS = Valve without solenoid	<b>R</b> = Reclaimed water ID handle
<b>PGV-101JT</b> = 1" Globe jar top valve, with flow control	<b>MM</b> = Male x male (NPT)	<b>DC</b> = DC latching solenoid	(Except for PGV-100JT)
	<b>MB</b> = Male NPT x 1" Barb	-	<b>CC</b> = Solenoid conduit cover
	MB075 = Male NPT x ¾" Barb		<b>DC</b> = DC latching solenoid
	<b>MB125</b> = Male NPT x 1¼" Barb		<b>AS-ADJ</b> = Accu Sync adjustable pressure regulator
			<b>AS-xx*</b> = Accu Sync pressure regulator <b>20</b> * = 20 PSI, <b>30</b> * = 30 PSI, <b>40</b> * = 40 PSI, <b>50</b> * = 50 PSI <b>70</b> * = 70 PSI

#### Examples:

**PGV-101JT-G** = 1" Globe jar top valve, with flow control, and 1" female

 $\textbf{PGV-101JT-GS-R} = 1" \ \text{Globe jar top valve, with flow control, slip x slip, and reclaimed water ID handle}$ 

**PGV-101JT-G-**R = 1" Globe jar top valve, with flow control, 1" female, and reclaimed water ID handle

 $\textbf{PGV-100JT-MB075-DC} = 1" \ \text{Globe jar top valve, without flow control, with 1" male x 34" barb, and DC latching solenoid and DC latching sole$ 

## PGV PRESSURE LOSS IN PSI

Flow GPM	<b>1"</b> Globe
01 M	
1	1.1
5	1.6
10	1.9
15	2.3
20	3.3
30	9.0
35	16
40	20

#### PGV-100G Installed

