

CS SAFETY AND MAINTENANCE INSTRUCTIONS

- Make sure that all electric connections and connection cables meet the pertaining regulations and are in conformity with the operating instructions.
- Do not overload electrical outlets or extension cords, fire or electric shocks can be the result
- Please contact an expert in case you have any doubts about the mode of operation, the safety or connecting the appliances.
- Keep all parts away from young children's reach
- Do not store this item on top, very cold or warm places, this can damage the electronic circuit boards.
- Avoid dropping or shocks, this can damage the electronic boards
- Never replace damaged power cables yourself! In such a case, remove them from the net and take the devices to a workshop.
- Repairs or opening of this item may only be performed by an authorised workshop.
- Wireless systems are subject to interference from cordless phones, microwaves, and other wireless devices operating in the 2.4GHz range. Keep the system AT LEAST 10 ft away from the devices during installation and operation.

Maintenance
The devices are maintenance-free, so never open them. The guarantee becomes void when you open the appliance. Only clean the outside of the devices with a soft, dry cloth or a brush. Prior to cleaning, remove the devices from all voltage sources.

Do not use any carboxylic cleaning agents or petrol, alcohol or similar. These attack the surfaces of the devices. Besides, the vapors are hazardous to your health and explosive. Do not use any sharp edged tools, screw drivers, metal brushes or similar for cleaning.

SICHERHEITS- UND WARTUNGSHINWEISE

- Stellen Sie sicher, dass alle elektrischen Anschlüsse sowie Kabelverbindungen an weitere Geräte den betreffenden Richtlinien entsprechen und sich gleichzeitig in Übereinstimmung mit der Bedienungsanleitung befinden
- Achten Sie darauf, Steckdosen und Verlängerungskabel nicht zu überlasten, das kann zu Feuer oder Stromschlag führen.
- Rufen Ihnen irgendwelche Zweifel an Betrieb, Sicherheit oder Anschluss der Geräte ausmachen, dann wenden Sie sich bitte an einen Fachmann.
- Alle Teile vor Kindern geschützt aufbewahren.
- Bitte nicht in feuchter, sehr kalter oder heißer Umgebung aufbewahren, das kann zu Beschädigung der elektronischen Schaltkreise führen.
- Vermeiden Sie harte Stöße, das kann zu Beschädigung der elektronischen Schaltkreise führen.
- Ersetzen Sie beschädigte Stromkabel niemals selbst! Nehmen Sie die Geräte vom Netz und wenden sich an einen Fachmann.
- Öffnen und Reparieren der Geräte ausschließlich durch autorisierten Fachbetrieb.
- Kabellose Systeme sind Störfeldern von kabellosen Telefonen, Mikrowellen sowie anderen elektronischen Geräten, die im 2.4GHz-Bereich arbeiten, ausgesetzt. Halten Sie einen MINDESTABSTAND VON WENIGSTENS 3 METERN während Installation und Betrieb ein.

Wartung
Die Geräte sind wartungsfrei, also öffnen Sie sie bitte nicht. Ihre Garantie verfällt, wenn Sie die Geräte öffnen. Reinigen Sie die Geräte außen mit einem weichen und trockenen Tuch oder einer Bürste. Vor dem Reinigen ziehen Sie bitte alle Stromzuführungen ab.

Verwenden Sie keine Reinigungsmittel, die Carbonsäure, Benzin, Alkohol oder ähnliches enthalten. Diese Mittel greifen die Oberfläche der Geräte an und die Ausdrüstungen sind gesundheitsschädlich und explosiv. Verwenden Sie keine scharfkantigen Werkzeuge, Schraubenzieher, Drahtbürsten oder ähnliches, um die Geräte zu reinigen.

VEILIGHEIDEN- EN ONDERHOUDSINSTRUCTIES

- Alle elektrische verbindingen en verbindingskabels moeten voldoen aan de juiste regels en overeenkomen met de bedieningsinstructies.
- Overbelast de elektrische stopcontacten of verlengsnoeren niet; dit kan anders leiden tot brand of elektrische schok.
- Neem contact op met een expert in geval je twijfels hebt over de bedieningswijze, de veiligheid of de aansluiting van de apparaten.
- Hou alle delen uit het bereik van kinderen.
- Zet dit voorwerp niet op natte, erg koude of warme plaatsen; dit kan de elektronische circuitboards beschadigen.
- Vermijd vallen of schokken; dit kan de elektronische board beschadigen.
- Vervang beschadigde stroomkabels nooit zelf! In dit geval verwijzen we u uit het net en breng de toestellen naar de winkel.
- Herstellingen of openen van dit voorwerp mag enkel gebeuren door een erkende hersteller.
- Draadloze systemen kunnen gestoord worden door draadloze telefoons, microgolven en andere draadloze toestellen die werken op het bereik van 2.4GHz. Hou het systeem MINSTENS op 3m afstand van de toestellen tijdens installatie en bediening.

Onderhoud
De toestellen zijn onderhoudsvrij, dus maak ze niet open. De garantie vervalt als je het apparaat opent. Reinig enkel de buitenkant van de toestellen met een zachte, droge doek of borstel. Vóór je ze reinigt, haal de toestellen uit alle spanningsbronnen.

Gebruik geen carboxylisch schoonmaakmiddelen of benzine, alcohol of gelijkaardige producten. Deze werken agressief op het oppervlak van de toestellen. Bovendien zijn de dampen gevaarlijk voor je gezondheid en ontbrandbaar. Gebruik geen scherpe instrumenten, schroevendraaiers, metalen borstels of gelijkaardige dingen om te reinigen.

INSTRUCTIONS DE SECURITE ET D'ENTRETIEN

- Vérifier que toutes les connexions électriques et câbles sont conformes aux règlements applicables et aux instructions d'utilisation.
- Ne pas créer de surtension sur les prises électriques ou les rallonges, cela peut être cause de feu ou d'électrocution.
- Contacter un expert en cas de doute sur le mode d'utilisation, de sécurité ou la connexion des appareils.
- Placer hors de portée des enfants.
- Ne pas disposer dans un endroit humide, très froid ou très chaud, cela pourrait endommager le tableau de circuits électroniques.
- Éviter de faire tomber ou de cogner les appareils; cela pourrait endommager le tableau de circuits électroniques.
- Ne jamais remplacer soi-même des fils électriques endommagés! Si les fils électriques sont endommagés, les retirer du réseau et les apporter dans un magasin spécialisé.
- La réparation et l'ouverture des différents éléments ne peuvent être effectuées que par un magasin spécialisé.
- Les systèmes sans fil sont sujets aux interférences des téléphones sans fil, des micro-ondes, et autres appareils sans fil utilisant la fréquence 2.4GHz. Placez le système AU MOINS à 3 mètres des ces appareils au cours de l'installation et au moment de l'utiliser.

Maintenance
Les appareils sont en libre utilisation, ne jamais les ouvrir. La garantie n'est plus valide si les appareils sont ouverts. Ne nettoyer que l'extérieur des appareils avec un chiffon doux et sec ou une brosse. Avant de nettoyer, débrancher les appareils.

Ne pas utiliser d'agents nettoyant à l'acide carboxylique ni d'essence, d'alcool ou autre produit de ce type. Ces produits attaquent la surface des appareils. Par ailleurs, les vapeurs sont dangereuses pour la santé et explosives. Ne pas utiliser d'ustensils à bout tranchant, de tournevis, de brosse métallique ou autre élément semblable pour le nettoyage.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment) (Applicable in the European Union and other European countries with separate collection systems)
This marking shows the product is for literature, indicates that it should not be disposed with other household waste (waste of common use). To prevent possible harm to the environment or human health from uncontrolled disposal, please dispose of this product in accordance with the following instructions.
To ensure the sustainable reuse of material resources, household users should ensure that the product is properly disposed of in accordance with the following instructions, for details of where and how they can take this item for environmentally safe recycling, please consult your local government or the local government office in charge of the purchase contract. This product should not be mixed with commercial wastes for disposal.

Korrekt Entsorgung dieses Produkts (Elektronik-Alt) (Anzuwenden in den Ländern der Europäischen Union und anderen europäischen Ländern mit einem separaten Sammel-System)
Dieses Markierung zeigt das Produkt ist für Literatur, zeigt an, dass es nicht mit anderen Haushaltsabfällen zusammen mit dem normalen Haushaltsabfall entsorgt werden darf. Entsorgen Sie dieses Gerät bitte getrennt von anderen Abfällen, um der Umwelt bzw. der menschlichen Gesundheit nicht schaden zu können. Bitte entsorgen Sie dieses Produkt in Übereinstimmung mit den folgenden Anweisungen.
Um die nachhaltige Wiederverwertung von Stofflichen Ressourcen zu fördern, Private User sollten sicherstellen, dass das Produkt gemäß wurde, oder ihre lokalen Behörden kontaktieren, um in Erfahrung zu bringen, wie sie das Gerät auf umweltfreundliche Weise recyceln können. Konsultieren Sie hierzu auch die örtlichen Behörden oder die zuständige Behörde für den Kaufvertrag. Dieses Produkt sollte nicht zusammen mit anderen gewerblichen Abfällen entsorgt werden.

Correcte verwijdering van dit product (elektronische & elektrische apparatuur)
Dit markering op het product of het bijbehorende informatieblad duidt erop dat het niet met ander huishoudelijk afval verwijderd moet worden aan het einde van zijn gebruiksdruk. Om mogelijke schade aan het milieu of de menselijke gezondheid door ongecontroleerd afvalverwijdering te voorkomen, moet u dit product van andere soorten afval scheiden en op een verantwoorde manier recycleren. Om de duurzame hergebruik van materiaalbronnen wordt bevordert. Huishoudelijke gebruikers moeten contact opnemen met de winkel waar het product is aangekocht of met de lokale overheid om te vernemen waar en hoe ze dit product milieuvriendelijk kunnen laten recycleren. Zakelijke gebruikers moeten contact opnemen met de leverancier of de algemene voorwaarden van de koopovereenkomst nalezen. Dit product moet niet worden gemengd met ander bedrijfsafval voor verwijdering.





Comment éliminer ce produit (déchets d'équipements électriques et électroniques) (Applicable en l'Union Européenne et dans d'autres pays européens disposant de systèmes de collecte sélective)
Ce symbole sur le produit ou sur l'étiquette d'information indique que le produit ne doit pas être éliminé avec les déchets ménagers. L'élimination inappropriée des déchets pourrait nuire à l'environnement ou à la santé humaine. Veuillez séparer des autres types de déchets et le recycler de façon responsable. Vous favorisez ainsi la réutilisation durable des ressources matérielles. Les particuliers sont invités à contacter le distributeur leur ayant vendu le produit ou à se renseigner auprès de leur mairie pour savoir où et comment ils peuvent se débarrasser de ce produit afin qu'il soit recyclé et respectant l'environnement. Les entreprises sont invitées à consulter leurs fournisseurs et à consulter les conditions de leur contrat de vente. Ce produit ne peut pas être éliminé avec les autres déchets commerciaux.

ELRO CS87T REAL-TIME DIGITAL CAMERA SYSTEM WITH TOUCH PANEL



RECORDING FORMAT
Frequency: 2.4 GHz FHSS modulated RF signal
Resolution: 840 x 480 (VGA) / 320 x 240 (QVGA)
SD card capacity: 32GB max. (excl.)
Battery operation time: 180min (3.7V Li-Pol)
Ports: 1. DC IN
2. Camera sensor
3. Camera sensor
4. Camera sensor
5. Camera sensor
6. Camera sensor
7. Camera sensor
8. Camera sensor
9. Camera sensor
10. Camera sensor
11. Camera sensor
12. Camera sensor
13. Camera sensor
14. Camera sensor
15. Camera sensor
16. Camera sensor
17. Camera sensor
18. Camera sensor
19. Camera sensor
20. Camera sensor
21. Camera sensor
22. Camera sensor
23. Camera sensor
24. Camera sensor
25. Camera sensor
26. Camera sensor
27. Camera sensor
28. Camera sensor
29. Camera sensor
30. Camera sensor
31. Camera sensor
32. Camera sensor
33. Camera sensor
34. Camera sensor
35. Camera sensor
36. Camera sensor
37. Camera sensor
38. Camera sensor
39. Camera sensor
40. Camera sensor
41. Camera sensor
42. Camera sensor
43. Camera sensor
44. Camera sensor
45. Camera sensor
46. Camera sensor
47. Camera sensor
48. Camera sensor
49. Camera sensor
50. Camera sensor
51. Camera sensor
52. Camera sensor
53. Camera sensor
54. Camera sensor
55. Camera sensor
56. Camera sensor
57. Camera sensor
58. Camera sensor
59. Camera sensor
60. Camera sensor
61. Camera sensor
62. Camera sensor
63. Camera sensor
64. Camera sensor
65. Camera sensor
66. Camera sensor
67. Camera sensor
68. Camera sensor
69. Camera sensor
70. Camera sensor
71. Camera sensor
72. Camera sensor
73. Camera sensor
74. Camera sensor
75. Camera sensor
76. Camera sensor
77. Camera sensor
78. Camera sensor
79. Camera sensor
80. Camera sensor
81. Camera sensor
82. Camera sensor
83. Camera sensor
84. Camera sensor
85. Camera sensor
86. Camera sensor
87. Camera sensor
88. Camera sensor
89. Camera sensor
90. Camera sensor
91. Camera sensor
92. Camera sensor
93. Camera sensor
94. Camera sensor
95. Camera sensor
96. Camera sensor
97. Camera sensor
98. Camera sensor
99. Camera sensor
100. Camera sensor
101. Camera sensor
102. Camera sensor
103. Camera sensor
104. Camera sensor
105. Camera sensor
106. Camera sensor
107. Camera sensor
108. Camera sensor
109. Camera sensor
110. Camera sensor
111. Camera sensor
112. Camera sensor
113. Camera sensor
114. Camera sensor
115. Camera sensor
116. Camera sensor
117. Camera sensor
118. Camera sensor
119. Camera sensor
120. Camera sensor
121. Camera sensor
122. Camera sensor
123. Camera sensor
124. Camera sensor
125. Camera sensor
126. Camera sensor
127. Camera sensor
128. Camera sensor
129. Camera sensor
130. Camera sensor
131. Camera sensor
132. Camera sensor
133. Camera sensor
134. Camera sensor
135. Camera sensor
136. Camera sensor
137. Camera sensor
138. Camera sensor
139. Camera sensor
140. Camera sensor
141. Camera sensor
142. Camera sensor
143. Camera sensor
144. Camera sensor
145. Camera sensor
146. Camera sensor
147. Camera sensor
148. Camera sensor
149. Camera sensor
150. Camera sensor
151. Camera sensor
152. Camera sensor
153. Camera sensor
154. Camera sensor
155. Camera sensor
156. Camera sensor
157. Camera sensor
158. Camera sensor
159. Camera sensor
160. Camera sensor
161. Camera sensor
162. Camera sensor
163. Camera sensor
164. Camera sensor
165. Camera sensor
166. Camera sensor
167. Camera sensor
168. Camera sensor
169. Camera sensor
170. Camera sensor
171. Camera sensor
172. Camera sensor
173. Camera sensor
174. Camera sensor
175. Camera sensor
176. Camera sensor
177. Camera sensor
178. Camera sensor
179. Camera sensor
180. Camera sensor
181. Camera sensor
182. Camera sensor
183. Camera sensor
184. Camera sensor
185. Camera sensor
186. Camera sensor
187. Camera sensor
188. Camera sensor
189. Camera sensor
190. Camera sensor
191. Camera sensor
192. Camera sensor
193. Camera sensor
194. Camera sensor
195. Camera sensor
196. Camera sensor
197. Camera sensor
198. Camera sensor
199. Camera sensor
200. Camera sensor
201. Camera sensor
202. Camera sensor
203. Camera sensor
204. Camera sensor
205. Camera sensor
206. Camera sensor
207. Camera sensor
208. Camera sensor
209. Camera sensor
210. Camera sensor
211. Camera sensor
212. Camera sensor
213. Camera sensor
214. Camera sensor
215. Camera sensor
216. Camera sensor
217. Camera sensor
218. Camera sensor
219. Camera sensor
220. Camera sensor
221. Camera sensor
222. Camera sensor
223. Camera sensor
224. Camera sensor
225. Camera sensor
226. Camera sensor
227. Camera sensor
228. Camera sensor
229. Camera sensor
230. Camera sensor
231. Camera sensor
232. Camera sensor
233. Camera sensor
234. Camera sensor
235. Camera sensor
236. Camera sensor
237. Camera sensor
238. Camera sensor
239. Camera sensor
240. Camera sensor
241. Camera sensor
242. Camera sensor
243. Camera sensor
244. Camera sensor
245. Camera sensor
246. Camera sensor
247. Camera sensor
248. Camera sensor
249. Camera sensor
250. Camera sensor
251. Camera sensor
252. Camera sensor
253. Camera sensor
254. Camera sensor
255. Camera sensor
256. Camera sensor
257. Camera sensor
258. Camera sensor
259. Camera sensor
260. Camera sensor
261. Camera sensor
262. Camera sensor
263. Camera sensor
264. Camera sensor
265. Camera sensor
266. Camera sensor
267. Camera sensor
268. Camera sensor
269. Camera sensor
270. Camera sensor
271. Camera sensor
272. Camera sensor
273. Camera sensor
274. Camera sensor
275. Camera sensor
276. Camera sensor
277. Camera sensor
278. Camera sensor
279. Camera sensor
280. Camera sensor
281. Camera sensor
282. Camera sensor
283. Camera sensor
284. Camera sensor
285. Camera sensor
286. Camera sensor
287. Camera sensor
288. Camera sensor
289. Camera sensor
290. Camera sensor
291. Camera sensor
292. Camera sensor
293. Camera sensor
294. Camera sensor
295. Camera sensor
296. Camera sensor
297. Camera sensor
298. Camera sensor
299. Camera sensor
300. Camera sensor
301. Camera sensor
302. Camera sensor
303. Camera sensor
304. Camera sensor
305. Camera sensor
306. Camera sensor
307. Camera sensor
308. Camera sensor
309. Camera sensor
310. Camera sensor
311. Camera sensor
312. Camera sensor
313. Camera sensor
314. Camera sensor
315. Camera sensor
316. Camera sensor
317. Camera sensor
318. Camera sensor
319. Camera sensor
320. Camera sensor
321. Camera sensor
322. Camera sensor
323. Camera sensor
324. Camera sensor
325. Camera sensor
326. Camera sensor
327. Camera sensor
328. Camera sensor
329. Camera sensor
330. Camera sensor
331. Camera sensor
332. Camera sensor
333. Camera sensor
334. Camera sensor
335. Camera sensor
336. Camera sensor
337. Camera sensor
338. Camera sensor
339. Camera sensor
340. Camera sensor
341. Camera sensor
342. Camera sensor
343. Camera sensor
344. Camera sensor
345. Camera sensor
346. Camera sensor
347. Camera sensor
348. Camera sensor
349. Camera sensor
350. Camera sensor
351. Camera sensor
352. Camera sensor
353. Camera sensor
354. Camera sensor
355. Camera sensor
356. Camera sensor
357. Camera sensor
358. Camera sensor
359. Camera sensor
360. Camera sensor
361. Camera sensor
362. Camera sensor
363. Camera sensor
364. Camera sensor
365. Camera sensor
366. Camera sensor
367. Camera sensor
368. Camera sensor
369. Camera sensor
370. Camera sensor
371. Camera sensor
372. Camera sensor
373. Camera sensor
374. Camera sensor
375. Camera sensor
376. Camera sensor
377. Camera sensor
378. Camera sensor
379. Camera sensor
380. Camera sensor
381. Camera sensor
382. Camera sensor
383. Camera sensor
384. Camera sensor
385. Camera sensor
386. Camera sensor
387. Camera sensor
388. Camera sensor
389. Camera sensor
390. Camera sensor
391. Camera sensor
392. Camera sensor
393. Camera sensor
394. Camera sensor
395. Camera sensor
396. Camera sensor
397. Camera sensor
398. Camera sensor
399. Camera sensor
400. Camera sensor
401. Camera sensor
402. Camera sensor
403. Camera sensor
404. Camera sensor
405. Camera sensor
406. Camera sensor
407. Camera sensor
408. Camera sensor
409. Camera sensor
410. Camera sensor
411. Camera sensor
412. Camera sensor
413. Camera sensor
414. Camera sensor
415. Camera sensor
416. Camera sensor
417. Camera sensor
418. Camera sensor
419. Camera sensor
420. Camera sensor
421. Camera sensor
422. Camera sensor
423. Camera sensor
424. Camera sensor
425. Camera sensor
426. Camera sensor
427. Camera sensor
428. Camera sensor
429. Camera sensor
430. Camera sensor
431. Camera sensor
432. Camera sensor
433. Camera sensor
434. Camera sensor
435. Camera sensor
436. Camera sensor
437. Camera sensor
438. Camera sensor
439. Camera sensor
440. Camera sensor
441. Camera sensor
442. Camera sensor
443. Camera sensor
444. Camera sensor
445. Camera sensor
446. Camera sensor
447. Camera sensor
448. Camera sensor
449. Camera sensor
450. Camera sensor
451. Camera sensor
452. Camera sensor
453. Camera sensor
454. Camera sensor
455. Camera sensor
456. Camera sensor
457. Camera sensor
458. Camera sensor
459. Camera sensor
460. Camera sensor
461. Camera sensor
462. Camera sensor
463. Camera sensor
464. Camera sensor
465. Camera sensor
466. Camera sensor
467. Camera sensor
468. Camera sensor
469. Camera sensor
470. Camera sensor
471. Camera sensor
472. Camera sensor
473. Camera sensor
474. Camera sensor
475. Camera sensor
476. Camera sensor
477. Camera sensor
478. Camera sensor
479. Camera sensor
480. Camera sensor
481. Camera sensor
482. Camera sensor
483. Camera sensor
484. Camera sensor
485. Camera sensor
486. Camera sensor
487. Camera sensor
488. Camera sensor
489. Camera sensor
490. Camera sensor
491. Camera sensor
492. Camera sensor
493. Camera sensor
494. Camera sensor
495. Camera sensor
496. Camera sensor
497. Camera sensor
498. Camera sensor
499. Camera sensor
500. Camera sensor
501. Camera sensor
502. Camera sensor
503. Camera sensor
504. Camera sensor
505. Camera sensor
506. Camera sensor
507. Camera sensor
508. Camera sensor
509. Camera sensor
510. Camera sensor
511. Camera sensor
512. Camera sensor
513. Camera sensor
514. Camera sensor
515. Camera sensor
516. Camera sensor
517. Camera sensor
518. Camera sensor
519. Camera sensor
520. Camera sensor
521. Camera sensor
522. Camera sensor
523. Camera sensor
524. Camera sensor
525. Camera sensor
526. Camera sensor
527. Camera sensor
528. Camera sensor
529. Camera sensor
530. Camera sensor
531. Camera sensor
532. Camera sensor
533. Camera sensor
534. Camera sensor
535. Camera sensor
536. Camera sensor
537. Camera sensor
538. Camera sensor
539. Camera sensor
540. Camera sensor
541. Camera sensor
542. Camera sensor
543. Camera sensor
544. Camera sensor
545. Camera sensor
546. Camera sensor
547. Camera sensor
548. Camera sensor
549. Camera sensor
550. Camera sensor
551. Camera sensor
552. Camera sensor
553. Camera sensor
554. Camera sensor
555. Camera sensor
556. Camera sensor
557. Camera sensor
558. Camera sensor
559. Camera sensor
560. Camera sensor
561. Camera sensor
562. Camera sensor
563. Camera sensor
564. Camera sensor
565. Camera sensor
566. Camera sensor
567. Camera sensor
568. Camera sensor
569. Camera sensor
570. Camera sensor
571. Camera sensor
572. Camera sensor
573. Camera sensor
574. Camera sensor
575. Camera sensor
576. Camera sensor
577. Camera sensor
578. Camera sensor
579. Camera sensor
580. Camera sensor
581. Camera sensor
582. Camera sensor
583. Camera sensor
584. Camera sensor
585. Camera sensor
586. Camera sensor
587. Camera sensor
588. Camera sensor
589. Camera sensor
590. Camera sensor
591. Camera sensor
592. Camera sensor
593. Camera sensor
594. Camera sensor
595. Camera sensor
596. Camera sensor
597. Camera sensor
598. Camera sensor
599. Camera sensor
600. Camera sensor
601. Camera sensor
602. Camera sensor
603. Camera sensor
604. Camera sensor
605. Camera sensor
606. Camera sensor
607. Camera sensor
608. Camera sensor
609. Camera sensor
610. Camera sensor
611. Camera sensor
612. Camera sensor
613. Camera sensor
614. Camera sensor
615. Camera sensor
616. Camera sensor
617. Camera sensor
618. Camera sensor
619. Camera sensor
620. Camera sensor
621. Camera sensor
622. Camera sensor
623. Camera sensor
624. Camera sensor
625. Camera sensor
626. Camera sensor
627. Camera sensor
628. Camera sensor
629. Camera sensor
630. Camera sensor
631. Camera sensor
632. Camera sensor
633. Camera sensor
634. Camera sensor
635. Camera sensor
636. Camera sensor
637. Camera sensor
638. Camera sensor
639. Camera sensor
640. Camera sensor
641. Camera sensor
642. Camera sensor
643. Camera sensor
644. Camera sensor
645. Camera sensor
646. Camera sensor
647. Camera sensor
648. Camera sensor
649. Camera sensor
650. Camera sensor
651. Camera sensor
652. Camera sensor
653. Camera sensor
654. Camera sensor
655. Camera sensor
656. Camera sensor
657. Camera sensor
658. Camera sensor
659. Camera sensor
660. Camera sensor
661. Camera sensor
662. Camera sensor
663. Camera sensor
664. Camera sensor
665. Camera sensor
666. Camera sensor
667. Camera sensor
668. Camera sensor
669. Camera sensor
670. Camera sensor
671. Camera sensor
672. Camera sensor
673. Camera sensor
674. Camera sensor
675. Camera sensor
676. Camera sensor
677. Camera sensor
678. Camera sensor
679. Camera sensor
680. Camera sensor
681. Camera sensor
682. Camera sensor
683. Camera sensor
684. Camera sensor
685. Camera sensor
686. Camera sensor
687. Camera sensor
688. Camera sensor
689. Camera sensor
690. Camera sensor
691. Camera sensor
692. Camera sensor
693. Camera sensor
694. Camera sensor
695. Camera sensor
696. Camera sensor
697. Camera sensor
698. Camera sensor
699. Camera sensor
700. Camera sensor
701. Camera sensor
702. Camera sensor
703. Camera sensor
704. Camera sensor
705. Camera sensor
706. Camera sensor
707. Camera sensor
708. Camera sensor
709. Camera sensor
710. Camera sensor
711. Camera sensor
712. Camera sensor
713. Camera sensor
714. Camera sensor
715. Camera sensor
716. Camera sensor
717. Camera sensor
718. Camera sensor
719. Camera sensor
720. Camera sensor
721. Camera sensor
722. Camera sensor
723. Camera sensor
724. Camera sensor
725. Camera sensor
726. Camera sensor
727. Camera sensor
728. Camera sensor
729. Camera sensor
730. Camera sensor
731. Camera sensor
732. Camera sensor
733. Camera sensor
734. Camera sensor
735. Camera sensor
736. Camera sensor
737. Camera sensor
738. Camera sensor
739. Camera sensor
740. Camera sensor
741. Camera sensor
742. Camera sensor
743. Camera sensor
744. Camera sensor
745. Camera sensor
746. Camera sensor
747. Camera sensor
748. Camera sensor
749. Camera sensor
750. Camera sensor
751. Camera sensor
752. Camera sensor
753. Camera sensor
754. Camera sensor
755. Camera sensor
756. Camera sensor
757. Camera sensor
758. Camera sensor
759. Camera sensor
760. Camera sensor
761. Camera sensor
762. Camera sensor
763. Camera sensor
764. Camera sensor
765. Camera sensor
766. Camera sensor
767. Camera sensor
768. Camera sensor
769. Camera sensor
770. Camera sensor
771. Camera sensor
772. Camera sensor
773. Camera sensor
774. Camera sensor
775. Camera sensor
776. Camera sensor
777. Camera sensor
778. Camera sensor
779. Camera sensor
780. Camera sensor
781. Camera sensor
782. Camera sensor
783. Camera sensor
784. Camera sensor
785. Camera sensor
786. Camera sensor
787. Camera sensor
788. Camera sensor
789. Camera sensor
790. Camera sensor
791. Camera sensor
792. Camera sensor
793. Camera sensor
794. Camera sensor
795. Camera sensor
796. Camera sensor
797. Camera sensor
798. Camera sensor
799. Camera sensor
800. Camera sensor
801. Camera sensor
802. Camera sensor
803. Camera sensor
804. Camera sensor
805. Camera sensor
806. Camera sensor
807. Camera sensor
808. Camera sensor
809. Camera sensor
810. Camera sensor
811. Camera sensor
812. Camera sensor
813. Camera sensor
814. Camera sensor
815. Camera sensor
816. Camera sensor
817. Camera sensor
818. Camera sensor
819. Camera sensor
820. Camera sensor
821. Camera sensor
822. Camera sensor
823. Camera sensor
824. Camera sensor
825. Camera sensor
826. Camera sensor
827. Camera sensor
828. Camera sensor
829. Camera sensor
830. Camera sensor
831. Camera sensor
832. Camera sensor
833. Camera sensor
834. Camera sensor
835. Camera sensor
836. Camera sensor
837. Camera sensor
838. Camera sensor
839. Camera sensor
840. Camera sensor
841. Camera sensor
842. Camera sensor
843. Camera sensor
844. Camera sensor
845. Camera sensor
846. Camera sensor
847. Camera sensor
848. Camera sensor
849. Camera sensor
850. Camera sensor
851. Camera sensor
852. Camera sensor
853. Camera sensor
854. Camera sensor
855. Camera sensor
856. Camera sensor
857. Camera sensor
858. Camera sensor
859. Camera sensor
860. Camera sensor
861. Camera sensor
862. Camera sensor
863. Camera sensor
864. Camera sensor
865. Camera sensor
866. Camera sensor
867. Camera sensor
868. Camera sensor
869. Camera sensor
870. Camera sensor
871. Camera sensor
872. Camera sensor
873. Camera sensor
874. Camera sensor
875. Camera sensor
876. Camera sensor
877. Camera sensor
878. Camera sensor
879. Camera sensor
880. Camera sensor
881. Camera sensor
882. Camera sensor
883. Camera sensor
884. Camera sensor
885. Camera sensor
886. Camera sensor
887. Camera sensor
888. Camera sensor
889. Camera sensor
890. Camera sensor
891. Camera sensor
892. Camera sensor
893. Camera sensor
894. Camera sensor
895. Camera sensor
896. Camera sensor
897. Camera sensor
898. Camera sensor
899. Camera sensor
900. Camera sensor
901. Camera sensor
902. Camera sensor
903. Camera sensor
904. Camera sensor
905. Camera sensor
906. Camera sensor
907. Camera sensor
908. Camera sensor
909. Camera sensor
910. Camera sensor
911. Camera sensor
912. Camera sensor
913. Camera sensor
914. Camera sensor
915. Camera sensor
916. Camera sensor
917. Camera sensor
918. Camera sensor
919. Camera sensor
920. Camera sensor
921. Camera sensor
922. Camera sensor
923. Camera sensor
924. Camera sensor
925. Camera sensor
926. Camera sensor
927. Camera sensor
928. Camera sensor
929. Camera sensor
930. Camera sensor
931. Camera sensor
932. Camera sensor
933. Camera sensor
934. Camera sensor
935. Camera sensor
936. Camera sensor
937. Camera sensor
938. Camera sensor
939. Camera sensor
940. Camera sensor
941. Camera sensor
942. Camera sensor
943. Camera sensor
944. Camera sensor
945. Camera sensor
946. Camera sensor
947. Camera sensor
948. Camera sensor
949. Camera sensor
950. Camera sensor
951. Camera sensor
952. Camera sensor
953. Camera sensor
954. Camera sensor
955. Camera sensor
956. Camera sensor
957. Camera sensor
958. Camera sensor
959. Camera sensor
960. Camera sensor
961. Camera sensor
962. Camera sensor
963. Camera sensor
964. Camera sensor
965. Camera sensor
966. Camera sensor
967. Camera sensor
968. Camera sensor
969. Camera sensor
970. Camera sensor
971. Camera sensor
972. Camera sensor
973. Camera sensor
974. Camera sensor
975. Camera sensor
976. Camera sensor
977. Camera sensor
978. Camera sensor
979. Camera sensor
980. Camera sensor
981. Camera sensor
982. Camera sensor
983. Camera sensor
984. Camera sensor
985. Camera sensor
986. Camera sensor
987. Camera sensor
988. Camera sensor
989. Camera sensor
990. Camera sensor
991. Camera sensor
992. Camera sensor
993. Camera sensor
994. Camera sensor
995. Camera sensor
996. Camera sensor
997. Camera sensor
998. Camera sensor
999. Camera sensor
1000. Camera sensor

USER'S MANUAL
BEODIENINGSANLEIDUNG
PODRECNIK UŽIVATELJA
HANDLEIDING
MANUEL DE L'UTILISATEUR
MANUAL DEL USUARIO



CS87T REAL-TIME DIGITAL CAMERA SYSTEM WITH TOUCH PANEL
This product allows for easy storage of images and audio, the maximum recording time depends on the used capacity. The system is provided with an external camera. The camera record options make the recorder suitable for different situations and demands. The camera can also be used to record with application in phone and internet pages. Download OMS card app.

CONTENTS

1. LCD monitor with wireless power with power adapter
2. Monitor base
3. Wireless camera with power adapter
4. Camera stand
5. Camera antenna
6. RAS cable

LCD MONITOR AND BASE VIEW (2)

1. Antenna
2. Power: - hold this button for at least 5 seconds to power on and for 3 seconds to power off.
3. DC IN jack
4. Reset
5. LCD screen
6. Base connector in monitor
7. Base connector in camera
8. DC IN jack
9. RAS cable connector

INSTALLATION
Before mounting the camera on a permanent spot, we recommend you to test the correct operation as follows:

1. Monitor the antenna (1) to the wireless camera (1) and then connect the camera to the power adapter. Plug the adapter to the wall outlet (3).
2. Put SD card into monitor (2) before turning the receiver on.
3. Switch the LCD monitor using the power button (2) and hold it at least for 5 seconds. Monitor the mounting place from camera bracket on the wall about 2.5m from the floor. Then mount the camera onto the bracket (4).

SYSTEM KAMERA CZYWOŁO DO NAGRYWANIA W CZASIE RECYWIZYWY CS87T Z PANELEM DOTYKOWYM
Dzięki produktowi umożliwia łatwą przechowywanie zdjęć i dźwięku, maksymalny czas nagrywania zależy od pojemności karty SD. Zestaw wyposażony jest w zewnętrzny aparat fotograficzny, który umożliwia nagrywanie w różnych sytuacjach i na różne potrzeby. Aparat może być również używany do nagrywania z aplikacji na telefonie i stronie internetowej.